

Bradax®



Manual Guide for Digital Water Flow Counter

UPPER COUNTER – one-time volume of water

LOWER COUNTER – total volume of water

Button A – one-time volume reset

Button B – total volume reset

Counter allows to measure up to 999,9 liters / gallons. Default measurement unit: liter. To change unit to gallons, push and hold button A for three seconds. After black, blinking button appears in lower left corner of display, push button B to set measurement unit. Confirm Your choice with button A.

Counter has already installed a battery. Battery save mode. If there is no button use or no water flow, display turns off automatically after 30 minutes.

Instrukcja obsługi licznika przepływu wody

GÓRNY LICZNIK – jednorazowa objętość przepływu wody

DOLNY LICZNIK – całkowita objętość przepływu wody

Przycisk A – zerowanie jednorazowego pomiaru

Przycisk B – zerowanie całkowitego pomiaru

Urządzenie pozwala na pomiar przepływu wody do 999,9 litrów/galonów. Licznik ma domyślnie ustawioną jednostkę: litr. W celu zamiany jednostki na galony, należy wcisnąć i przytrzymać ok. trzech sekund przycisk A. Po pojawieniu się czarnej kropki w lewym dolnym rogu wyświetlacza, wybieramy za pomocą przycisku B żadaną jednostkę miary. Wybór potwierdzamy przyciskiem A.

Urządzenie posiada już zamontowaną baterię.

Tryb oszczędnościowy baterii: wyświetlacz wyłączy się automatycznie po około 30 minutach, jeśli nie będzie wykonywana żadna czynność przyciskami A i B lub jeśli nie będzie przepływu wody.